



OIL CHANGE

PERFORMING MAINTENANCE OIL CHANGE

1 Warm up the Oil - Turn the unit on and let it run for approximately 5 minutes to warm the oil.



2 Remove the Red Breather Cap - Locate and remove the Red Breather Cap from the pump head.



3 Extract the Old Oil - Use an Oil Extractor to remove all of the oil out of the Pump Head Cavity.



4 Add the New Oil - Add approximately 8.5 oz of 302-Non Detergent Oil. The oil level should reach the middle dot on the front sight glass.



TOOLS NEEDED

- 302-NON DETERGENT OIL (SKU: 57025/57030)
- OIL EXTRACTOR (SKU: 57033)

THAT'S IT!

Your pump's oil is now changed and ready for optimal performance! It is recommended to change your pump's oil every 500 working hours.